

POWER CONTROLLER
RP7



USER'S MANUAL



POWER CONTROLLER

RP7 TYPE

USER'S MANUAL

CONTENTS

1. APPLICATION	5
2. BASIC REQUIREMENTS, OPERATIONAL SAFETY	5
3. POWER CONTROLLER SET	7
4. DESCRIPTION OF THE DESIGN and OPERATION	7
5. INSTALLATION and SETTING TO WORK	9
6. SPECIFICATIONS	10
7. ORDERING CODES	12
8. MAINTENANCE AND GUARANTEE	13

1. APPLICATION

The RP7 power controller is destined to control the load power in function of the input control signal for following types of loads:

- resistance loads,
- resistance-inductance loads, and the control of induction motors and commutator motors at not high loads.

The application area of RP7 power controllers includes:

- electrical furnaces and drying constructions, particularly industrial tunnel and belt-type furnaces, furnaces for annealing and hard soldering, crucible furnaces and furnaces for hardening in salt bath,
- devices of mechanical engineering, aggregates and extruding presses for plastics, devices for winding and tempering of springs, spot welding and seam welders,
- production of glass and glazing, installations and devices for drying in infrared and ultraviolet radiation, ladles for glass melt and heating of feeding devices,
- chemical and petroleum industries, facing heaters of tube installations, preheating installations

2. BASIC REQUIREMENTS, OPERATIONAL SAFETY

Power controllers are applied in high-current installations in which devices under voltage can be a source of danger.

Considering the personnel safety, one should observe following principles:

- Devices can be installed, serviced and maintained exclusively by a suitably qualified personnel, having essential knowledge about equipment. RP7 power controllers should be connected to the power network according to the present operative regulations and standards concerning electrical installations, and concerning specially the protection against electric shocks.
- During the start and operation of the starting system. One must comply with recommendations included in this user's manual. Qualified personnel defines persons which are acquainted with the user's manual, assembly starting and service of the product, and have appropriate qualifications to carry out these activities.

Symbols located in this user's manual mean:



WARNING!

Warning of potential, hazardous situations. Especially important. One must be familiar with this before connecting the power controller. The non-observance of notices marked by these symbols can occasion severe injuries of the personnel and the damage of the device.



CAUTION!

Designates a general useful note. If you observe it, handling of the power controller is made easier. One must take note of this, when the power controller is working inconsistently to the expectations. Possible consequences if disregarded!

In the security scope the power controller meets the requirements of the EEC Low-Voltage Directive (EN 61010 -1 issued by CENELEC).

Remarks concerning the operator safety:

1. General

- The RP7 power controller is destined to co-operate with other devices.
- Non-authorized removal of the required housing, inappropriate use, incorrect installation or operation creates the risk of injury to personnel or damage to equipment. For more detailed information please study the user's manual.
- All operations concerning transport, installation, and commissioning as well as maintenance must be carried out by qualified, skilled personnel and national regulations for the prevention of accidents must be observed.
- According to this basic safety information, qualified, skilled personnel are persons who are familiar with the installation, assembly, commissioning, and operation of the product and who have qualifications necessary for their occupation.

2. Transport, storage

Please observe the notes on transport, storage and appropriate handling. Observe the climatic conditions given in Technical Data.

3. Installation

- The power controller must be installed according to the regulation and instructions given in this user's manual.
- Ensure proper handling and avoid mechanical stress.
- Do not bend any components and do not change any insulation distances.
- Do not touch any electronic components and contacts.
- Electronic Instruments may contain electrostatically sensitive components, which can easily be damaged by inappropriate handling.
- Do not damage or destroy any electrical components since this might endanger your health!

4. Electrical connection

- Before switching the power controller on, one must check the correctness of connection to the network.
- In case of the protection terminal connection with a separate lead one must remember to connect it before the connection of the power controller to the mains.
- When working on live instruments or devices, the applicable national regulations for the prevention of accidents must be observed.
- The electrical installation must be carried out according to the appropriate regulations (cable cross-sections, fuses,). Additional information can be obtained from the user's guide.
- The documentation contains information about installation in compliance with EMC (shielding, grounding, filters and cables). These notes must be observed for all CE-marked products.
- The manufacturer of the installation or installed devices is responsible for the compliance with the required limit values demanded by the EMC legislation.

5. Operation

- Installations including RP7 power controllers must be equipped with protection devices according to the corresponding standard and regulations for prevention of accidents.

- After the power controller has been disconnected from the supply voltage, live components and power connections must not be touched immediately because capacitors can be charged.
- The housing must be closed during operation.

6. Maintenance and servicing

- Please observe the manufacturer's documentation.
- Read all product-specific safety and application notes in this user's manual.
- Before taking the power controller housing out, one must turn the supply off.
- The removal of the power controller housing during the guarantee contract period may cause its cancellation.

3. POWER CONTROLLER SET

The set consists of:

- RP7 power controller 1 pc.
- user's manual 1 pc.
- guarantee card 1 pc.
- fuse 1 pc

When unpacking the power controller, please check the delivery completeness and whether the type and version code on the data plate correspond to the order.

4. DESCRIPTION OF THE DESIGN AND OPERATION

The RP7 power controller is destined to be mounted on a wall or on a rail (E-06292, DIN EN 50 022-35) by means of a special catch.

Power controller overall dimensions, spacing of assembly holes and the fixing way are presented on the fig. 1.




Fig. 1. Overall and assembly dimensions

- 1 - protection cover, 2 - terminal strip, 3 - terminal \oplus of the protection wire
 4 - fuse, 5 - DIP switch, 6 - radiator, 7 - catch, 8 - rail.

Servicing elements are disposed on the power controller frontal plate.

- terminal strip, enabling the connection of load circuit wires, control wires or the potentiometer,
- potentiometer „ I_{lim} ”, serving to the load current limitation,
- potentiometer „ α_{max} ”, serving to the triggering angle limitation,
- lighting green diode (1), signalling the exceeding over 70% of the set power,
- lighting red diode (2), signalling the fuse damage.

The RP7 power controller has a bidirectional thyristor switch, which is a link controlled by the gate triggering system. It also includes a fuse destined to protect semiconductor elements, an RC two-terminal network and a varistor, protecting against commutation or connection overvoltages.

The connection of the load is realised by the change of the load current connection angle in the function of the control analog signal or by means of the potentiometer.

Runs of signals for this control are shown on the fig. 2.




Fig. 2. Phase control, runs of occurring signals

The RP7 power controller has functions ensuring a reliable and safe operation:



● Limitation of the current load

If the current value in the load circuit exceeds the threshold value set by the „ I_{lim} ” potentiometer, then the current limitation will operate independently on the control signal.

The maximal value of the current flowing in the load circuit can be set in the range from 20% to 100% I_o (for rated power load higher than 1/2 maximal power of the power controller).

● Limitation of the triggering angle

In case of power controller work with motors on can set the current I_r value necessary for the motor start by means of the „ α_{max} ” potentiometer.

The control range in this case is depended on the set current I_r value to the rated current I_n value. If the control signal value is lower than the value corresponding to the I_r value, then the triggering stoppage follows.

● **Triggering delay of „Soft-start” type**

The „soft-start” type enables the change of the connection angle from π to 0 rad in the time ca 1.5 s, after the supply connection (switch W, fig. 3).

● **Detection and signalling of the load circuit current**

The 70% exceeding of the set current limitation value is signalled by the lighting of the green diode - 1

● **Signalling of fuse damage**

In case of the fuse damage, the voltage on fuse terminals supplies the signalling system of the fuse damage (lighting of the red diode - 2).

5. INSTALLATION AND SETTING TO WORK

After fixing the power controller according to the fig. 1, one must carry out connections of external circuits as shown on the fig. 3.




Fig. 3. Marking and description of external terminals

Cross-sections of supply wires:

- to the load circuit (U1 and U2 terminals) $\geq 1.5 \text{ mm}^2$
- to the system of gate triggering (U terminal) $\geq 0.35 \text{ mm}^2$
- protective lead (terminal \oplus) $\geq 1.5 \text{ mm}^2$

Maximal cross-section of supply wires: 2.5 mm^2

Connect the L1, N supply to terminals 1 (U), 3 (U2).

Connect the load between the terminal 2 (U1) and the phase L1 of the supply voltage.

One must connect the input signal to terminals 4 (0 V), 5 (U/I).

The manufacturer input signal is set on 0...10 V.

The range of the input signal and the adaptation of the power controller to the load type can be chosen by the appropriate position of the DIP switch section, accessible after removing the power controller cover, fig. 1.

The way of the switch setting is given in the table 1.

		Switch sections				
		1	2	3	4	5
Control signal	0...5 V	0	1	0	0	
	0...10 V	0	0	0	0	
	0...20 mA	1	1	0	0	
	4...20 mA	1	1	1	1	
Kind of load	Resistance	-	-	-	-	0
	Resistance-in-ductance	-	-	-	-	1

0 - switch in OFF position

1 - switch in ON position

In case of assignment from the potentiometer, set the control signal on the range 0...10.

The power controller setting to work includes:

- The setting of the load current limitation (set the handwheel of the „ α_{max} ” potentiometer on maximum).

Set the handwheel of the „ I_{lim} ” potentiometer on minimum. Observing indications of the instrument measuring the load current (at the maximal value of the input control signal), set the required value of the load current by means of the „ I_{lim} ” potentiometer handwheel.

- The setting of the triggering angle limitation (use at the control of motor rotational speed).

Set the handwheel of the „ α_{max} ” potentiometer on maximum. Set the value of the control signal corresponding to the current I_r necessary to start the motor. Then, turn the „ α_{max} ” potentiometer handwheel till the moment of the triggering stoppage.

6. SPECIFICATIONS

Continuous input signal:

0...5 V	input resistance: 3 k Ω
0...10 V	input resistance: 6 k Ω
0...20 mA	input resistance: 250 Ω
4...20 mA	input resistance: 250 Ω

Assignment from the potentiometer potentiometer: 10 k Ω

Maximal output current 5 A, 10 A, 15 A

The characteristic of the load capacity is presented on the fig. 4.




Fig. 4. Maximal output current value in the function of the ambient temperature

Supply voltage of the load circuit	195... <u>230</u> ...253 V a.c
Supply voltage frequency	47... <u>50</u> ...53 Hz
Power consumption of the gate triggering system	≤ 3.3 VA
Minimal current output	100 mA
Value of the output current in the locking state	≤ 15 mA (230 V)

Power generated on the triac:

Table 2

Maximal output current	[A]	5	10	15
Power generated on the triac	[W]	8	17	24

Value of the relative error to map the static characteristic ± 10%
 Value of the expected short-circuit current of the supply voltage source 2 kA

Fuse parameters:

Table 3

Max. output current [A]	5	10	15
Kind of fuse	Wickmann FF 6,3 A or Bussmann GBB-6	Wickmann FF 12,5 A or Bussmann GBB-12	Wickmann FF 16 A or Bussmann GBB-20
$\int i^2 dt$ [A ² s]	< 15	< 40	< 120

Working temperature	0...50°C
Storage temperature	- 25...70°C
Atmosphere pressure	86...106 kPa
Humidity class	DIN 40040 „F”
Working height	up to 1000 m at rated load
Test voltage	VDE 0160 tab. 4, Category II
Overvoltage category	E-08109, VDE 0110 part.1, category II
Isolation between circuits	basic
Admissible pollution level	VDE 0110, part 2, level 2
Noise immunity	IEC 801-2, 2 kV IEC 801-4, 8 kV
Safe disconnection	VDE 0160 5.6
Operating conditions	VDE 0160 5.5.1.3
Place of use	VDE 0875, part 3
Manufacturing	VDE 0558, part 1
Working position	vertical
Housing protection degree	IP 20, E-08106, VDE0470
Overall dimensions	50 × 105 × 105 mm
Weight	0.5 kg

7. ORDERING CODES

Code	Description
RP7 300	Power controller RP7 maximum output current 5A; documentation in English; test certificate

8. MAINTENANCE AND GUARANTEE

The RP7 power controller does not require any special periodical maintenance.

In case of a fuse damage, the red diode (2) lights.

To replace the fuse, one must:

- disconnect the load circuit supply,
- disconnect electrical connections from the terminal strip,
- remove the power controller protection cover,
- replace the fuse.

NOTE: The radiator can be hot. Be careful.



In case of some other incorrect operations:

After the dispatch date and within the period stated in the guarantee card

One should return the power controller to the Manufacturer's Quality Inspection Dept.

If the device has been used in compliance with the instructions, the Manufacturer guarantees to repair it free of charge.

The disassembling of the housing causes the cancellation of the granted guarantee.

After the guarantee period:

One should send the device to repair it in an authorized service workshop.

Spare parts are available for the period of five years from the date of purchase.

Our policy is one of continuous improvement and we reserve the right to make changes in design and specifications of any products as engineering advances or necessity requires and revise the above specifications without notice.



LUMEL

LUMEL S.A.

ul. Słubicka 4, 65-127 Zielona Góra, Poland
tel.: +48 68 45 75 100, fax +48 68 45 75 508
www.lumel.com.pl

Technical support:

tel.: (+48 68) 45 75 143, 45 75 141, 45 75 144, 45 75 140
e-mail: export@lumel.com.pl

Export department:

tel.: (+48 68) 45 75 130, 45 75 132
e-mail: export@lumel.com.pl

Calibration & Attestation:

e-mail: laboratorium@lumel.com.pl