

TRANSDUCER OF TEMPERATURE
AND STANDARD SIGNALS
P20



USER'S MANUAL



Contents

1. APPLICATION	5
2. TRANSDUCER SET	5
3. OPERATIONAL SAFETY	6
4. INSTALLATION	7
4.1. Fitting way	7
4.2. External electrical connection diagrams	8
5. SERVICE	9
5.1. Transducer configuration by means of the eCon software	10
5.1.1 Configuration of the transducer input type	11
5.1.2 Configuration of the individual analog output characteristic	12
5.1.3 Configuration of the analog output at overflows	13
5.1.4 Readout of the measured value	14
5.1.5 Readout of the serial number and software version	15
6. TECHNICAL DATA	16
7. EXECUTION CODES	18
8. MAINTENANCE AND GUARANTEE	20

1. APPLICATION

The P20 programmable transducer is designed to convert temperature, resistance, voltage from a shunt and standard signals into a constant-current or constant-voltage standard signal.

The output signal is galvanically isolated from the input signal and supply.

The transducer compensates automatically the resistance of wires in case of resistance value measurements in a three-wire system and automatically compensates the temperature of terminals in case of measurements from thermocouples.

The transducer is fully configurable through the PD14 programmer. By means of this programmer, one can change the input type, the measurement averaging time and rescale the analog output acc. to the individual output characteristic, and also read out the measured value.

2. TRANSDUCER SET

The set of the P20 transducer is composed of:

- P20 transducer 1 pc.
- User's manual 1 pc.
- Plug with screw terminals 2 pcs.
- Hole plug of the programmer socket 1 pc

When unpacking the transducer, please check whether the type and execution code on the data plate correspond to the order.

3. OPERATIONAL SAFETY



In the safety service scope, the transducer meets to requirements of the EN 61010-1 standard.

Observations concerning the operational safety

- All operations concerning transport, installation, and commissioning as well as maintenance, must be carried out by qualified, skilled personnel, and national regulations for the prevention of accidents must be observed.
- Before switching transducer on, one must check the correctness of connections to the network.
- When connecting the supply, one must remember that a switch or a circuit-breaker should be installed in the building. This switch should be located near the device, easy accessible by the operator, and suitably marked as an element switching the transducer off.
- Do not connect the transducer to the network through an autotransformer.
- Before removing the transducer housing, one must switch the supply off and disconnect measuring circuits.
- The removal of the transducer housing during the guarantee contract period may cause its cancellation.
- The programmer socket is only use to connect the PD14 programmer. After the transducer programming, one must insert the hole plug.
- Non-authorized removal of the housing, inappropriate use, incorrect installation or operation, creates the risk of injury to personnel or a transducer damage.

For more detailed information, please study the User's Manual.

4. INSTALLATION

4.1. Fitting way

P20 transducers are designed to be mounted on a 35 mm rail according to EN 60715.

Housing dimensions are: 22.5 x 120 x 100 mm.

On the transducer outside, there are screw or self-locking terminal strips, which make possible the connection of external wires with a 2.5 mm² cross-section (supply and output) and up to 1.5 mm² (input).





Fig. 1. Overall dimensions and fitting way of the transducer

Transducers should be mounted on the rail in direct contact with another devices that emit heat (eg transducer P20). You must keep a minimum 5 mm distance between the devices to allow emit heat from the housings to the ambient. Otherwise, the in rated operating temperature of transducer which is in direct contact with the other transducer may exceed the rated operating temperature stated operating conditions.


4.2. External electrical connection diagrams

The transducer has two sockets of terminal strips, which two plugs with terminal screws are connected to. The way to connect external signals is shown on the fig. 1


The electrical connection diagram is also situated on the transducer housing. In case of the transducer work in an environment with high interferences, one must apply shielded wires in the transducer input.



RTD in a three-wire system





RTD in a two-wire system or resistance measurement



TC or voltage
- 60... 60 mV
0... 60 mV
- 150... 150 mV
0... 150 mV

Voltage
- 10... 10 V
0... 10 V
0... 5 V




Current
- 20... 20 mA
0... 20 mA
4... 20 mA

Fig.2. Electrical connection diagrams of the P20 transducer.

5. SERVICE

After switching the transducer on, the work state diode should light in red for a moment, next it should light in green.



Diode of the transducer work state:

- the state diode lights in green – normal work,
- the state diode lights in red – improper work parameters; one must configure the transducer again,
- the state diode pulsates in red – lack of calibration or the non-volatile memory is damaged; one must return the transducer to the manufacturer.

Fig. 3. View of the P20 transducer

Confirmation of the separator's communication with PD14 programmer is indicated by the status diode which turns off for short period of time.

5.1. Transducer configuration by means of the eCon software

The eCon software is destined for the P20 transducer configuration. One must connect the PC computer through the PD14 programmer and configure the connection choosing **Communication -> Serial port** from the menu (for the P20 transducer, we choose the address 1, baud rate 9600 kb/s, the mode RTU 8N2 and the appropriate port COM under which the controller of the PD14 programmer has been installed).




Fig. 4. Configuration of the connection with the P20 transducer.

After configuring the connection, use the **Connect**  button. The eCon software will automatically identify the device and connect to it and display all parameters in the panel **P20- Configuration**. To change parameters, enter the new value in the parameter window and click the **Save** button.

5.1.1 Configuration of the transducer input type

In the parameter group **Input configuration** there are 3 expandable lists available, by means of which you can select the input type, measuring range and measurement averaging time. The changes must be confirmed by clicking the **Save** button.

P20 - configuration

↓ ↑ 📁 📄 📄 PDF 👤

▼ Input configuration

Input type	Thermoresistor Pt100	▼
Measuring range	-200...850 °C	▼
Measure averaging time	<input type="text" value="500"/>	[100 - 30000] ms
<input type="button" value="Save"/>		

▶ Individual characteristic configuration

▶ Output exceedings configuration

▶ Measured values

Fig. 5. View of the eCon software window "Input configuration"

5.1.2. Configuration of the analog output characteristic


The P20 transducer enables the conversion of measured values into an output signal on the base of the individual linear characteristic of the analog output. On the base of given by the user coordinates of two points, the transducer determines (from the system of equations) coefficients **a** and **b** of the individual characteristic.

$$\begin{cases} Y1\ Out = a \cdot X1\ In + b \\ Y2\ Out = a \cdot X2\ In + b \end{cases}$$

where:

X1 In and X2 In – measured value

Y1 Out and Y2 Out – expected value on the output



The X1 In value on the transducer input
=> Y1 Out value on the analog output
The X2 In value on the transducer input
=> Y2 Out value on the analog output
Other points of the characteristic are calculated

Fig. 6. Individual characteristic of analog outputs




Fig. 7. View of the eCon software window “Individual characteristic configuration”

5.1.3. Configuration of the analog output at overflows

The user has the additional possibility in the P20 transducer to configure the preservation of the analog output after the signal overflow occurrence on the measuring input. By default, the service of overflows is switched out – then, after the signal overflow on the input, the output is still proportional to the steered up input beyond the basic output range. After switching the overflow service on, the user can define himself by which value the output is to be steered up after the occurrence of the higher or lower overflow.




Fig. 8. View of the “Output exceedings configuration” window of the eCon software.

5.1.4. Readout of the measured value

By means of the eCon software you can also read the value currently measured, check the type of output. These values can be found in the **Measured values** window. To display the window, go to the **Measured values** tab and use the **Show** button.




Fig.9. View of the “Measured values” window of the eCon software

Measured values	
Stop values refreshing	
Reg.	Value
Measured value	923.45 °C
Analog output steering	106.99 %
Analog output type	0...20 mA

Fig.10. View of the “Measured values” window of the eCon software

5.1.5. Readout of the serial number and software-version

The serial number and the software version can be found in the upper right corner of the configuration panel.




Fig.11. View of serial number and software version in the eCon software

6. TECHNICAL DATA

Basic parameters:

- analog output galvanically isolated:
 - current 0/4...20 mA
 - voltage 0...10 V
 - maximal load resistance of the current output $\leq 500 \Omega$
 - minimal load resistance of the voltage output $\geq 500 \Omega$
- accuracy class¹⁾ 0.2
- averaging time of the transducer:
 - range: d.c. current [mA], d.c. voltage [V] ≥ 0.1 s
 - other ranges ≥ 0.3 s
- consumption < 2 VA
- preheating time of the transducer 10 min
- transducer response time:
 - range: d.c. current [mA], d.c. voltage [V] ≥ 0.2 s
 - other ranges ≥ 0.4 s
- current flowing through RTD < 0.2 mA
- resistance of wires connecting RTD with the transducer $\leq 10 \Omega$

Rated operating conditions:

- supply depending on the execution code 85... 253 V a.c./d.c.
20...85 V d.c., 20...65 V a.c.
- frequency of the supply a.c. voltage 45... 65 Hz
- ambient temperature $- 20...23...55^{\circ}\text{C}$
- storage temperature $- 25...85^{\circ}\text{C}$
- related air humidity $< 95\%$ (condensation inadmissible)
- working position any

Input parameters:

- resistance of voltage input [V] $> 1 \text{ M}\Omega$
- resistance of current input [mA] $12 \Omega \pm 1\%$

Sustained overload:

- TC and RTD $1.1 X_n$
- voltage, current and resistance $1.3 X_n$

Short duration overload:

- voltage input $5 U_n$
- current input $10 I_n$

Ensured protection level**acc. to EN 60529:**

- housing IP 40
- from terminal side IP 20

Dimensions:

22.5 × 100 × 120 mm

Weight:

0.125 kg

Fitting

on a 35 mm DIN rail,
acc. to EN 60715

Electromagnetic compatibility:

- noise immunity EN 61000-6-2
- noise emission EN 61000-6-4

Safety requirements acc. to EN 61010-1:

- installation category III
- pollution degree 2
- phase-to-earth working voltage:
 - supply $300 \text{ V}^{2)}$
 - input 50 V
 - output 50 V
- altitude above sea level $< 2000 \text{ m}$

1) A part of sub-ranges for thermocouples and RTD has a specified individual class – see table 3

2) Execution for supply voltage 230 V.

7. EXECUTION CODES

Execution codes of the P20 transducer

Table 2.

TRANSDUCER	P20 -	X	X	XX	XX	X
Analog outputs:						
current 0... 20 mA.....		1				
current 4... 20 mA.....		2				
voltage 0... 10 V		3				
Supply:						
85...253 V a.c./d.c.		1				
20 ... 85 V d.c., 20...65 V a.c.		2				
Kind of input						
see table 3.....				XX		
Execution:						
standard						00
custom-made*						XX
Acceptance tests:						
without extra quality requirements						8
with an extra quality inspection certificate						7
with test certificate.....						4
acc. to customer's requirements*						X

* after agreeing with the manufacturer

Type of sensor/input	Range [°C]	Kod			
Pt100 RTD	-200...850 0...850 0...600 0...400 0...200 -200...200 -100...100*	01	TC of K type	-200...1370	36
		02		0...1200	37
		03		0...1000	38
		04		0...800	39
		05		0...600	40
		06		0...400*	41
		07		-200...200*	42
Pt250 RTD	-200...850 0...850 0...600 0...400 0...200 -200...200 -100...100	08	TC of S type	0...1760	43
		09		0...1600	44
		10		0...1400*	45
		11		0...1200*	46
		12		0...1000*	47
Pt500 RTD	-200...850 0...850 0...600 0...400 0...200 -200...200 -100...100	13	TC of N type	-200...1200	48
		14		0...1200	49
		15		0...1000	50
		16		0...800	51
		17		0...600*	52
		18		0...400*	53
		19		-200...200*	54
Pt1000 RTD	-200...850 0...850 0...600 0...400 0...200 -200...200 -100...100	20	d.c. voltage	0...10 V	55
		21		0...5 V	56
		22		-10...10 V	57
		23		-5...5 V	58
		24		0...60 mV	59
		25		-60...60 mV	60
		26		0...150 mV	61
27	-150...150 mV	62			
TC of J type	-200...1200 0...1200 0...1000 0...800 0...600 0...400* -200...200*	28	d.c. current	0...20 mA	63
		29		4...20 mA	64
		30		0...5 mA	65
		31		-20...20 mA	66
		32		0...400 Ω	67
	0...1000 0...800 0...600 0...400* -200...200*	33	Resistance	0...4000 Ω	68
		34			
		35			
Custom-made execution					XX

* accuracy class 0,5

Example of order:

When ordering, please respect successive code numbers.

The code: **P20-1.1.04.00.7** means:

P20 – transducer of temperature and standard signals

1 – with current analog output: 0...20 mA,

1 – voltage supply: 85...253 V a.c./d.c.,

04 – Pt100 input signal, 0...400°C range,

00 – standard execution

7 – with an extra quality inspection certificate

8. MAINTENANCE AND GUARANTEE

The P20 transducer does not require any periodical maintenance.

In case of some incorrect operations:

After the dispatch date and in the period stated in the guarantee card:

One should return the transducer to the Manufacturer's Quality Inspection Dept.

If the instrument has been used in compliance with the instructions, we guarantee to repair it free of charge.

The disassembling of the housing causes the cancellation of the granted guarantee.

After the guarantee period:

One should turn over the instrument to repair it in a certified service workshop.

Spare parts are available for the period of five years from the date of purchase.

We reserves the right to make changes in design and specifications of any products as engineering advances or necessity requires.



LUMEL S.A.

ul. Sulechowska 1, 65-022 Zielona Góra, POLAND
tel.: +48 68 45 75 100, fax +48 68 45 75 508
www.lumel.com.pl,
e-mail: lumel@lumel.com.pl

Export department:

tel.: (+48 68) 45 75 139, 45 75 233, 45 75 321, 45 75 386
fax.: (+48 68) 32 54 091
e-mail: export@lumel.com.pl